


Multiport Valve Series



MPVA-02



MPVA-03



MPVA-04

MULTIPOINT VALVE :

1. FILTER (Normal filtration and vacuuming)
2. Backwash (Cleaning filter by reversing the flow)
3. Rinse (Used after backwash to flush dirt from valve)
4. Waste (By-passes filter, used for vacuuming to waste or lowering water level)
5. Recirculate (By-passes filter for circulation water to pool)
6. Closed (Shuts off all flow to filter or Pool)
7. Winterize (This device is used to prevent freezing)(Only Eight Position)
8. Service (The screw on the handle should be replaced when repairing. (Only Eight Position))



MPV-01

Item Number	Valve position	Pipe size (inch)	Body colour	Mounting location
OXY-MPV-01	8	1.5	White	Top
OXY-MPV-02	6	2	Black	Top
OXY-MPV-03	8	1.5	Black	Side
OXY-MPV-04	6	2	Black	Side